



LAWN MOWER



Depending on the model purchased, packaging will contain different accessories and parts.
Refer to the package for more details.


KNOW YOUR PRODUCT

- 1 Power button
- 2 Blade activation lever
- 3 Upper handle
- 4 Lower handle shafts
- 5 Rear door
- 6 Height adjustment lever
- 7 Battery door
- 8 Side discharge door
- 9 LED headlight
- 10 Grass catcher
- 11 Self-propelled drive lever
- 12 Mulch plug
- 13 Side discharge chute




1 INSTALLATION

Install the upper handle



2 Adjust the handlebar position

Adjust the handlebar position



Europe
www.greenworkstools.eu



USA
www.greenworkstools.com



Canada
www.greenworkstools.ca

Cutting Configuration


This lawn mower is designed for three cutting configurations (rear bagging/mulching/side discharging). These configurations can be achieved with different accessory combinations. Please refer to the configuration table below.

TO CONVERT MOWER	MULCH PLUG	GRASS BAG	SIDE DISCHARGE CHUTE
For rear bagging	×	✓	×
For mulching	✓	×	×
For side discharging	✓	×	✓

"✓" : installed
"×" : removed


4 Rear bagging setup

Configuration 1: Rear Bagging




5 Mulching setup

Configuration 2: Mulching




Side discharging setup

Configuration 3: Side discharging




Self-propelled drive system




7

Cutting height adjustment



8

Install/remove the batteries




9

OPERATION

Start the product


10



11

MAINTENANCE

Mower blade replacement



12

13

